


GENERAL

The In-Seat Power Supply System (ISPSS) provides electrical power to the In-Seat Power Supply Unit (ISPSU) outlets located in the passenger seats, enabling the use of Portable Electronic Devices (PED). It is possible for the flight crew to simultaneously disconnect power from all ISPSUs, via a single switch.

CONTROLS

On the overhead panel :



- AUTO : Powers all ISPSUs.
- OFF : Simultaneously turns off all ISPSUs.
- INOP : This label indicates that the ISPSS has been deactivated and is inoperative. ⚠