

	ICE AND RAIN PROTECTION ELECTRICAL SUPPLY			1.30.80	P 1
				SEQ 001	REV 17

BUS EQUIPMENT LIST

			NORM			EMER ELEC		
			AC	DC	DC BAT	AC ESS	DC ESS	HOT
WING ANTI ICE	INNER VALVES			DC1				
	OUTER VALVES			DC1				
ENG ANTI ICE	ENG 1 and ENG 3			DC2				
CLOSURE	ENG 2 and ENG4			DC1				
WINDOW HEAT	WHC	1		DC1				
		2		DC2				
	HEATING POWER	L	AC1-1					
		R	AC2-4					
PROBE HEAT	PHC	CAPT OR STBY			X			
		F/O		DC2				
	STATICS	CAPT OR STBY		DC1				
		F/O		DC2				
	PITOT	CAPT				X (1)		
		F/O	AC2-3					
		STBY	AC1-2 (1)					
	AOA	CAPT	AC1-1					
		F/O	AC2-3					
		STBY	AC1-2					
RAIN REMOVAL	WIPER	CAPT		DC1				
		F/O		DC2				
	RAIN REPELLENT 	CAPT					X	
		F/O		DC2				
ICE DETECT SYSTEM 	ICE DETECTION	PROBE 1	AC1					
	ICE DETECTION	PROBE 2	AC2-3					
WATER/WASTE ANT-ICE	WIPCU 1 and 2			DC2				
	HEATING ELEMENTS AND DRAIN MAST		AC1-1					

(1) When AC1–2 is lost and AIR DATA is switched to "CAPT ON 3", the standby PITOT is switched to AC ESS BUS, and the Captain's pitot heading is lost.