

virgin atlantic A340-600 Flight crew operating Manual	LANDING GEAR			1.32.50	P 1
	ELECTRICAL SUPPLY			SEQ 001	REV 17

BUS EQUIPMENT LIST

		NORM			EMERELEC		
		AC	DC	DC BAT	AC ESS	DC ESS	HOT
LANDING GEAR	LGCIU 1					LAND RECOV	
	LGCIU 2		DC2				
	SAFETY VALVE		DC1/DC2				
	GRVTY EXT SYS 1						HOT 1
	GRVTY EXT SYS 2						HOT 2
	LDG GEAR INDICATOR PANEL					X	
NWS	OVERSTEER WARNING 		DC1				HOT 1 (*)
BRAKES	BSCU CHANNEL 1		DC1				
	BSCU CHANNEL 2		DC2				
	PARK BRK CTL		GND/FLT				HOT 1
	BRK FAN CTL 		DC2				
	COOLING FANS WHEEL 1, 2, 3, 4 	AC2-3					
	COOLING FANS WHEEL 5, 6, 7, 8 	AC1-2					
TIRE PRESS	TIREPRESS INDICATING UNIT 		DC1				

(*) : Or the tow tractor power supply.