

BUS EQUIPMENT LIST

FOR INFO

	NORM			EMER ELEC			
	AC	DC	DC BAT	AC ESS	DC ESS	HOT	APU BAT BUS
ECB SUPPLY					X (2)		X (1)
STARTERMOTOR	APU TR						X

- (1) ECB is supplied by APU HOT BUS on ground if APU BAT BUS is not supplied
- (2) This supply is necessary only during the APU start (due to a loss of voltage on the APU BAT BUS during this phase).