

STARTING PROCEDURE QUICK REFERENCE



lyushin IL-18D and IL-18T (cargo version)
by **AEROPROYECTO**







FUEL VALVE, ENG 1 = ON
Allows the fuel flow to engine 1


3

FEED VALVE, ENG 1-2 = ON
Allows to feed engines 1 and 2 from the left feed cell

4

FUEL PUMP, ENG 1 = ON
Send the fuel from the feed cell to engine 1

5



GENERATOR SWITCHS = ON
Connect the power generator of engine 1. Engine 1 must be running

9

MASTER SWITCH = ON
Energize the starting panel

6

START BUTTON = PRESS
Start the selected engine. Must be pressed until the engine starts. Check fuel flow **ENGINE Nº1**

8

POWER SOURCE SELECT = ON BOARD
Connect all the electric systems to the on board suppliers. Batteries, Generators or APU.

10

ENGINE SELECTOR = 1
Selects the engine that will be started

7

The previous explanation was to start the engine 1.
To start the rest of the engines follows the steps from 3 to 9, using switches according to the engine number.

Edgar Guinart López
aroquefc@infomed.sld.cu