

ALMATY

STANDS CHARACTERISTICS

Apron	Stand	Coordinates	
		Latitude	Longitude
1	01	43 20 39.58 N	077 00 50.87 E
1	01	43 20 40.44 N	077 00 53.51 E
1	02	43 20 41.52 N	077 00 49.72 E
1	02	43 20 42.42 N	077 00 52.35 E
1	03	43 20 44.71 N	077 00 49.27 E
1	04	43 20 46.98 N	077 00 47.22 E
1	05	43 20 48.35 N	077 00 46.56 E
1	06	43 20 50.08 N	077 00 45.48 E
1	07	43 20 51.44 N	077 00 44.40 E
1	08	43 20 54.12 N	077 00 43.35 E
1	12	43 20 47.99 N	077 00 57.61 E
1	12	43 20 47.04 N	077 00 54.76 E
1	13	43 20 49.16 N	077 00 53.44 E
1	13	43 20 50.18 N	077 00 56.24 E
1	14	43 20 50.86 N	077 00 52.39 E
1	16	43 20 55.26 N	077 00 50.22 E
1	17	43 20 56.34 N	077 00 49.55 E
1	18	43 20 57.42 N	077 00 48.87 E
1	19	43 20 58.66 N	077 00 48.10 E
1	20	43 20 59.72 N	077 00 47.43 E
1	21	43 21 00.78 N	077 00 46.77 E
1	22	43 21 01.83 N	077 00 46.11 E
1	23	43 21 02.89 N	077 00 45.45 E
1	24	43 21 03.86 N	077 00 44.84 E
1	25	43 21 05.12 N	077 00 44.05 E
1	26	43 21 06.63 N	077 00 43.10 E
1	27	43 21 07.96 N	077 00 42.27 E
1	28	43 21 09.30 N	077 00 41.43 E
1	29	43 21 10.48 N	077 00 40.69 E
1	30	43 21 11.42 N	077 00 40.10 E
1	31	43 21 12.36 N	077 00 39.51 E
1	31A	43 21 13.30 N	077 00 38.92 E
1	32	43 21 10.38 N	077 00 37.56 E
1	32	43 21 09.87 N	077 00 36.04 E
1	32A	43 21 10.95 N	077 00 35.38 E
1	32A	43 21 11.45 N	077 00 36.89 E
1	33	43 21 08.78 N	077 00 36.70 E
1	33	43 21 09.30 N	077 00 38.24 E
1	34	43 21 07.70 N	077 00 37.36 E
1	34	43 21 08.22 N	077 00 38.92 E
1	35	43 21 05.53 N	077 00 40.61 E
1	36	43 21 04.19 N	077 00 41.45 E
1	37	43 21 02.97 N	077 00 42.22 E
1	38	43 21 01.39 N	077 00 43.21 E
1	39	43 21 00.29 N	077 00 43.90 E
1	40	43 20 59.21 N	077 00 44.58 E
1	41	43 20 58.15 N	077 00 45.25 E
1	42	43 20 39.07 N	077 00 47.21 E
1	42A	43 20 39.98 N	077 00 46.65 E
1	43	43 20 38.15 N	077 00 47.78 E
1	43A	43 20 37.25 N	077 00 48.34 E
1	44	43 20 36.34 N	077 00 48.91 E
1	45	43 20 35.43 N	077 00 49.47 E
1	46	43 20 34.53 N	077 00 50.03 E
1	46A	43 20 33.62 N	077 00 50.59 E
1	47	43 20 54.80 N	077 00 57.23 E
1	48	43 20 54.69 N	077 00 59.51 E
1	49	43 20 54.58 N	077 01 01.79 E
1	50	43 20 54.47 N	077 01 04.07 E
1	51	43 20 54.37 N	077 01 06.20 E
1	52	43 20 54.28 N	077 01 08.21 E
1	53	43 20 54.18 N	077 01 10.24 E
1	54	43 20 54.09 N	077 01 12.26 E
1	55	43 20 53.99 N	077 01 14.27 E
1	56	43 20 53.89 N	077 01 16.30 E
1	57	43 20 51.30 N	077 01 15.27 E
1	58	43 20 51.35 N	077 01 14.12 E
1	59	43 20 51.61 N	077 01 08.72 E
1	59B	43 20 49.87 N	077 01 08.60 E
1	60	43 20 51.74 N	077 01 06.14 E
1	60B	43 20 49.30 N	077 01 06.09 E
1	60B	43 20 50.00 N	077 01 06.04 E

Apron	Stand	Coordinates	
		Latitude	Longitude
1	61	43 20 35.59 N	077 00 53.91 E
1	62	43 20 36.07 N	077 00 55.38 E
1	63	43 20 36.64 N	077 00 53.39 E
1	64	43 20 38.12 N	077 00 52.43 E
2	65	43 21 04.80 N	077 01 17.78 E
2	66	43 21 04.93 N	077 01 14.17 E
2	67	43 21 05.06 N	077 01 10.60 E
2	68	43 21 05.19 N	077 01 06.98 E
2	69	43 21 03.15 N	077 01 02.82 E
2	69	43 21 05.35 N	077 01 02.97 E
1	71	43 20 51.41 N	077 01 12.96 E
1	72	43 20 51.47 N	077 01 11.82 E
1	73	43 20 51.52 N	077 01 10.66 E
1	74	43 20 49.50 N	077 01 15.14 E
1	75	43 20 49.56 N	077 01 13.98 E
1	76	43 20 49.61 N	077 01 12.83 E
1	77	43 20 49.67 N	077 01 11.68 E
1	78	43 20 49.73 N	077 01 10.54 E