AERODROME GROUND MOVEMENT AND AIRCRAFT PARKING CHART-ICAO

STEPANAKERT / APP / TWR 122.3
ALTERNATE 130.3

STEPANAKERT



Not to scale

BEFORE TAKE-OF
AFTER LANDING

APRON:
Strength-STANDS:
0A, 0B, 1, 2 PCN 23/S/C/W/T

WARNING:
1.TWY A is closed.
2.TWY D is closed.
3. Apron 1 is closed.
4. Apron 3 is closed

STANDS:
0A, 0B Airbus 319
1, 2 CRJ-100, SuperJet-100, Jetstream 31

NOTE: All stands can be used by another type of aircraft, which external dimension is similar with mentioned types.

Width: A - 18 m
B - 16 m
C - 16 m
D - 13 m

Surface: Asphalt-concrete all taxiways

TAXIWAYS: A- N/U
B- PCN 23/S/C/W/T
C- PCN 23/S/C/W/T
D- N/U

STAND	Latitude	Longitude
0A	39° 53' 58.88"N	046° 47' 14.87"E
0B	39° 53' 58.40"N	046° 47' 13.89"E
1	39° 53' 59.41"N	046° 47' 17.19"E
2	39° 53' 56.84"N	046° 47' 11.87"E